


Sequence for the Installtion of uPVC Pipes

1. Construct substation structure wall with the required wall opening
Refer to the typical details for the wall opening size .
2. Apply the water stop around the wall opening and uPVC pipe ,
and position the uPVC pipes inside the wall opening.
3. Formwork should be used to support the uPVC pipes and
seal both ands of the wall opening .
No other material should be used or left inside the wall opening to support the uPVC pipes.
4. Inject non - shrink grout into the wall opening and allow sufficient time
for the grout to set before removing the formwork .

E				
D				
C				
B				
A				
	Date	Modification	Draft.	Verif.
			Approv.	

Draft.	Antonio	01/04/2021	Customer Substation (P.T.) Civil Construction	
Verif.	V. Lopes	01/04/2021		
Approv.	V. Lopes	01/04/2021		
Typical Details of Trench outlet 電纜出線位標準大樣圖				TAD
Scale		Remarks	Job Nº	Drawing Nº E-566